

FIG. 1

.**.**




FIG. 2

_;






FIG. 3

+



CONFIGURATION MESSAGE

<u>600</u>




TOPOLOGY CHANGE NOTIFICATION MESSAGE

FIG. 6

+

<u>700</u>



PORT STATE TABLE PRIOR ART

FIG. 7

1




FIG. 8

 \perp

9,000

	910 }	912	913
	STATE	ROLE	UPLINKGUARD ENABLED
914~	FWD	ROOT PORT	DON'T CARE
916~	FWD	DESIGNATED PORT	NO
918	BLK	BLOCKED PORT	DON'T CARE
920~	BLK	UPLINK GUARD ENABLED BACKUP FOR ROOT PORT	DON'T CARE
922_	UPLINKGUARD INCONSISTENT = BLK	DESIGNATED	YES

PORT STATE TABLE

FIG. 9

+






FIG. 10
